



SVT 28



SVT 40



SVL 50



SVL 70



VS 200/180



SVL 450

## 安全阀

型号	编号	流量		最大压力		额定温度	进水口	出水口	维修包编号	重量	
		l/min	gpm	bar	psi					g	件/箱
SVT 28	<b>0215010200</b>	25	6,6	280	4060	150°C	2x3/8"GF	3/8"GF	<b>4079900012</b>	390	24
SVT 40	<b>0215010420</b>	25	6,6	400	5800	90°C	2x3/8"GF	3/8"GF	<b>4079900034</b>	490	5
SVL 50	<b>4073500003</b>	100	26,4	560	8100	90°C	1/2"GF	1/2"GF	<b>4079900048</b>	1420	1
SVL 70	<b>4073201000</b>	60	16	720	10450	90°C	3/8"GF	1/2"GF	<b>4079900033</b>	2000	1
VS 200/180	<b>60.5100.15</b>	200	53	200	2900	90°C	3/4"GF	1/2"GF	<b>60.5110.24</b>	820	4
SVL 450	<b>4073500001</b>	450	120	220	3200	90°C	1" GF	1" GF	<b>4079900036</b>	4650	1
	<b>4073500002</b>	450	120	330	4800	90°C	1" GF	1" GF	<b>4079900036</b>	4800	1

- 安全阀需安装人员正确调试后才能起到安全保护功能